


Body Control Module (BCM) X3



Connector Part Information

- Harness: Body
- OEM: 15492675
- Service: 15404825
- Description: 41-Way F Metri-Pack 280, 800 Series (RD)

Terminal Part Information

- Pin: D1
- Terminal/Tray: 12110127/19
- Core/Insulation Crimp: F/G
- Release Tool/Test Probe: 12150860/J-35616-44 (YE)
- Pins: 17, A8, B3 (without UE1 or U2K), B5 (without MN5), C12
- Terminal/Tray: 12110844/4
- Core/Insulation Crimp: E/4
- Release Tool/Test Probe: 15315247/J-35616-4A (PU)
- Pins: A1, A3, A9-A12, B1, B3 (with UE1 or U2K)
- Terminal/Tray: 12110844/4
- Core/Insulation Crimp: E/A
- Release Tool/Test Probe: 15315247/J-35616-4A (PU)
- Pins: A2, A4, A5, C3
- Terminal/Tray: 12110842/4
- Core/Insulation Crimp: C/A
- Release Tool/Test Probe: 15315247/J-35616-4A (PU)
- Pins: C5, D5, D6, D10, D12
- Terminal/Tray: 15324340/19
- Core/Insulation Crimp: F/G
- Release Tool/Test Probe: 12094430/J-35616-4A (PU)

Body Control Module (BCM) X3

Pin	Wire	Circuit	Function
-----	------	---------	----------

Pin	Wire	Circuit	Function
A1	0.5 TN	294	Door Lock Actuator – Unlock Control (AU3 or UE1)
A2	0.5 TN	294	Door Lock Actuator – Unlock Control (AU3) (Sedan)
A3	0.5 TN	294	Door Lock Actuator – Unlock Control (AU3) (Sedan)
A3	0.5 D-BU/WH	149	Courtesy Lamp Supply Voltage
A4	0.5 GY	295	Door Lock Actuator – Lock Control (AU3/UE1) (Driver)
A4	0.5 GY	295	Door Lock Actuator – Lock Control (AU3) (Passenger)
A5	0.5 GY	295	Door Lock Actuator – Lock Control (AU3) (Sedan)
A5	0.5 GY	295	Door Lock Actuator – Lock Control (AU3) (Sedan)
A6	—	—	Not Used
A7	0.35 BN	9	Park Lamp Supply Voltage
A8	0.35 PK	339	Run/Crank Ignition Voltage (KA1)
A9	0.5 YE	18	Left Rear Stop/Turn Lamp Supply Voltage
A10	0.5 GY	157	Courtesy Lamp Control
A11	—	—	Not Used
A12	0.5 D-GN	19	Right Rear Stop/Turn Lamp Supply Voltage
B1	0.5 TN	694	Driver Door Lock Actuator – Unlock Control (AU3/UE1)
B2	—	—	Not Used
B3	0.35 RD/WH	1240	Battery Positive Voltage (LAP)
B3	0.5 RD/WH	1240	Battery Positive Voltage (UE1 or U2K)
B4	—	—	Not Used
B5	0.35 BN	4	Accessory Voltage
B5	0.35 BN	4	Accessory Voltage (MN5)
B6–B7	—	—	Not Available

© 2019 General Motors. All rights reserved.

Pin	Wire	Circuit	Function
B8-B11	—	—	Not Used
B12	0.35 GY	8	I/P Lamp Supply Voltage (LAP)
	0.35 GY	8	I/P Lamp Supply Voltage (LAP)
C1-C2	—	—	Not Available
C3	1 D-GN	1301	Retained Accessory Power Fuse Supply Voltage
C4	—	—	Not Used
C5	3 D-GN	801	Retained Accessory Power Fuse Supply Voltage
C6-C7	—	—	Not Available
C8-C11	—	—	Not Used
C12	0.35 OG	228	Windshield Washer Pump Control
D1	5 RD/BK	142	Battery Positive Voltage
D2	—	—	Not Available
D3	—	—	Not Used
D4	0.5 RD/WH	840	Battery Positive Voltage
D5	3 D-GN	801	Retained Accessory Power Fuse Supply Voltage
D6	3 PK	739	Run/Crank Ignition Voltage
D7	0.35 PK	1339	Ignition Voltage
	0.35 PK	1339	Ignition Voltage
D8-D9	—	—	Not Used
D10	3 RD/BK	442	Battery Positive Voltage
D11	—	—	Not Used
D12	3 RD/WH	242	Battery Positive Voltage